

3M Safety-Walk Primer 901

SKU: 83-0781

AMERICAN
PERMALIGHT



1 can = 32 Fl. oz.

3M Safety Walk Primer can be used to enhance adhesion on many porous surfaces, such as concrete step surfaces, before the application of Anti-Slip Tape.

Directions for Use

Surface Preparation:

Before the application of Safety-Walk Primer, prepare and thorough CLEAN the surface following the *Installation Instructions* included with the Anti-Slip Tape. You must make sure that the Installation Surface is thoroughly cleaned: dust- and grime free, dry.

Application of Safety-Walk Primer:

1. The surface must be clean, dry, smooth and above 50°F (10°C) prior to the application of Safety-Walk Primer.
2. Mix contents thoroughly before use.
3. Brush on an even coat over the surface that shall be marked with the Anti-Slip Tape.
4. Allow **Primer to dry thoroughly** before applying Anti-Slip Tape.
5. Apply the Anti-Slip Tape by following the Tape Application Instructions, using a Pressure-Roller to firmly press-apply the tape to the primed area.
6. Be sure to reseal the Primer Can tightly after use.

DANGER! Extremely Flammable Liquid and Vapor. May cause eye and skin irritation. Vapor overexposure may cause respiratory tract damage. May be absorbed through skin. Contains a chemical which can cause cancer, birth defects reproductive harm. Consult the 3M SDS – *Safety Data Sheets* before starting to work with this primer.

VOC – Volatile Organic Compound: 583 grams/liter.

California Prop 65 Warning: 3M Safety Walk Primer may expose you to Toluene, n-Hexane, Ethylbenzene, Xylene and other trade-protected ingredients, substances known to the State of California to cause cancer, birth defects and reproductive harm. Avoid contact and use safeguards for personal protection. For more information, go to <https://oehha.ca.gov/proposition-65/chemicals/>

September 2021